




METALMASTER®





ROOF FOOTBRIDGE,
VERTICAL

VALC PROFILE

INSTALLATION GUIDE

ROOF FOOTBRIDGE, VERTICAL
Valc profile



VALC PROFILE (3 m) roof footbridge installation kit		Kit
Pos.	Name	Quantity
1.	ZK-bracket plate	3*
2.	ZL-bracket plate	3*
3.	535 mm C-bracket	3*
4.	RP-bracket	6*
5.	M8x35 screw	6*
6.	M8 washer	6*
7.	M8 nut	6*
8.	Roof footbridge (3 m)	1*
9.	M8x20 screw	6*
10.	M8 nut	6*
11.	M8 washer	6*
12.	M10x20 screw	6*
13.	M10 nut	6*
14.	M10 washer	6*

* Quantity depends on the number of kits.

VALC PROFILE (1.12 m) roof footbridge installation kit		Kit
Pos.	Name	Quantity
1.	ZK-bracket plate	2*
2.	ZL-bracket plate	2*
3.	535 mm C-bracket	2*
4.	RP-bracket	4*
5.	M8x35 screw	4*
6.	M8 washer	4*
7.	M8 nut	4*
8.	Roof footbridge (1.12 m)	1*
9.	M8x20 screw	4*
10.	M8 nut	4*
11.	M8 washer	4*
12.	M10x20 screw	4*
13.	M10 nut	4*
14.	M10 washer	4*

* Quantity depends on the number of kits.




Figure 1.

Safety!

- One person, weighing up to 120 kg, may be on a roof footbridge!
- Use certified safety ties when moving on a roof footbridge!
- In winter, clear snow from the roof footbridge before stepping onto it!
- Do not use roof footbridges with visible damage or defects!

Before installing a roof footbridge:

- Plan the location for installation.
- Make sure that the roof structure is stable.
- It is recommended to install the roof footbridge on top of the roof battens.
- Check to confirm that the roofing is installed according to the roof installation instructions.
- Before installing the supports, mark a straight line in which you plan to install the roof footbridges, e.g., using a coloured chalk line.
- Make sure that the roof footbridge is installed in a straight line.

• **Roof footbridge installation:**

- Install the ZK- and ZL-bracket plates and place them at one side of the roof seam such that they are in a vertical position (Figure 2).
 - Place the RP-bracket on the other side of the seam (Figure 2).
 - Each ZK- and ZL-bracket plate must be fastened together with an RP-bracket (Figure 2).
 - Make sure that the RP-bracket parts are in the position shown in Figure 2.
 - Screw together using an M8x35 mm bolt screw, M8 nut, and washer (Figure 2).
 - Tighten the screws such that the RP-bracket plate holds firmly on the roof material (Figure 2).
 - To the ZK- and ZL-bracket plates, attach the C-bracket using two M8x20 screws with an M8 nut and M8 washer (Figure 2).
 - Fasten the roof footbridge to the C-bracket using two M10x20 screws and an M10 nut and M10 washer (Figure 2).
 - The maximum distance between the ZK- and ZL-bracket plates and platform ends is 935 mm, and 100 mm from the platform ends (Figure 1).
 - Roof footbridge can be easily extended by connecting one to the other.
-




Figure 2.




Figure 3.